Philips
Sandwich maker

900 W

HD2417

Large plates

Digital timer

Power-on and ready-to-use lights

Removable, dishwasher-safe plates

Vertical, compact storage

Have it your way, exactly your way

Set the timer for delicious sandwiches

Have your sandwiches just the way you want them. Place any sandwich you like between the large plates and select your preferred timing. The non-stick, removable, dishwasher safe plates make cleaning easier than ever before.

Delicious sandwiches
- Fits all kinds of sandwiches thanks to the large plates
- Quick and delicious results thanks to the 900W of power

Exactly the way you like
- Digital timer with audible ready-signal
- Power-on and ready-to-use lights

In the easiest way
- Easy cleaning thanks to removable, dishwasher-safe plates
- Vertical, compact storage
- Finger-print proof metal housing

PHILIPS
sense and simplicity

Sandwich maker
900 W

HD2417

Specifications

General specifications
- Non-stick coated plates
- Cool-touch handle
- Cord storage
- Anti-slip feet

Technical Specifications
- 900 W
- 50/60 Hz
- 220-240 V
- Cord length: 0.9 m

Design specifications
- Colour: Black/metal/red
- Materials: Phenolic housing, metal insert on top

Product highlights

Large plates
Fits all kinds of sandwiches thanks to the large plates

Digital timer
Digital timer with audible ready-signal

Removable, dishwasher-safe plates
Easy cleaning thanks to removable, dishwasher-safe plates

Finger-print proof metal housing
Finger-print proof metal housing

Date of issue 2007-02-24

Version: .0

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com